

Quick Guide Bluetooth Music Receiver WM-BT30

Compatible with the following models:

- Toyota 4Runner 2007-2009
- Toyota Avalon 2007-2009
- Toyota Camry 2007-2009
- Toyota Corolla 2007-2009
- Toyota FJ Cruiser 2007-2009
- Toyota Highlander 2007-2009
- Toyota Land Cruiser 2007-2009
- Toyota Matrix 2007-2009
- Toyota Prius 2007-2009
- Toyota RAV4 2007-2009
- Toyota Tacoma 2007-2009
- Toyota Tundra 2007-2009
- Toyota Yaris 2007-2009

Connect the adapter:

1. Remove the radio (you will find various instructions on the Internet).
2. Before you disconnect the plugs from the radio, make sure that you have the radio code available to you, as you may need it for the radio after the power interruption.
3. Disconnect the 20 pin connector from the radio. If external devices such as a CD changer are present, this cannot be used afterwards.
4. Insert the 20 pole extender of the WM-BT30 into the provided connector behind the radio.
5. Now connect the black ground cable to the radio housing or the black cable directly to a ground cable to the radio connection (usually a thick brown cable). Without a good ground connection the function of the adapter is not given.
6. Now connect the red cable (ignition plus +12V) to a switched +12V line (measurement with multimeter necessary). Ignition on = +12V on / ignition off = 0V on.
7. Establish a Bluetooth connection by enabling Bluetooth pairing and searching for the Bluetooth device ``WM``. You should then set the volume of the connected device to full volume.
8. Before you reinstall the radio, test the function of the adapter. Switch on the AUX function using the CD/AUX button or the menu on the radio.

For Info!

AUX must be enabled and selectable on the radio. If this is not the case, it must be activated in a specialist workshop.

Has something been left unclear? You can reach us MO-FR by mail: service@watermark-germany.de