

Quick Guide Bluetooth Music Receiver WM-BT45

Compatible with the following models:

- **Nissan**

Tiida (C11) 2004-2011, Versa (C11) 2004-2011, Micra (K12) 2005-2010, Note (E11) 2005-2013, Qashqai (J10) 2006-2013, X-Trail (T31) 2007-2014, Navara (D40) 2005-2015, NV200 from year 2009

Only in conjunction with Clarion Radio !

- **Suzuki**

Ignis from year 2016, Swift (FZ/NZ) 2010-2017, Grand Vitara (JT) 2005-2015, SX4 S-Cross from year 2013, Jimny from year 2005-2016

Only in conjunction with Clarion Radio PS-2656D-A, PS-2991D-B, PS-3025K-B, PS-3101D-A, PS-2681H-B

- **Subaru**

Forester (SH) 2008-2013, Forester (SJ) from 2012, Impreza (GR) 2007-2013, Impreza ab Bj. 2013, XV 2011-2018, Legacy (BL/BP) 2007-2009 (CD/AUX Radio button), Legacy (BM/BR) 2009-2014 (CD/AUX Radio button), Legacy (BN/BS) from year 2014, Outback (BP) 2008-2009 (CD/AUX Radio button), Outback (BR) 2009-2014 (CD/AUX Radio button), Outback (BS) from year 2015

Only in conjunction: Panasonic 6 disc CD XV, McIntosh PF-2343I-A, PF-2510I-A, PF-4025I-C, PF-4048I-A, PF-4062I, C-123 , C-124

connect the adapter:

1. remove the radio (you will find various instructions on the Internet).
2. Before you disconnect the plugs from the radio, make sure that you have the radio code available to you, as you may need it for the radio after the power interruption.
3. disconnect the 8-pin connector from the radio. If an external CD changer is present, it can no longer be used.
4. Insert the 8-pin plug of the WM-BT45 into the connector provided behind the radio.
5. Now connect the black ground cable to the radio housing or the black cable directly to a ground cable to the radio connection (usually a thick brown cable). Without a good ground connection the function of the adapter is not given.
6. Now connect the red cable (ignition plus +12V) to a switched +12V line (measurement with multimeter necessary). Ignition on = +12V on / ignition off = 0V on.
7. Establish a Bluetooth connection by enabling Bluetooth pairing and searching for the Bluetooth device ``WM``. You should then set the volume on the connected device to full volume.
8. Before you reinstall the radio, test the function of the adapter. Switch on the AUX function using the CD/AUX button on the radio.

For Info!

AUX must be enabled and selectable on the radio. If this is not the case, it must be activated in a specialist workshop.

Has something been left unclear? You can reach us MO-FR by mail: service@watermark-germany.de