

## Quick Start Guide Bluetooth Music Receiver WM-BT50

### Compatible with the following models:


- FORD Fiesta Bj. 2005-2008
- FORD Fusion Bj. 2005-2010
- FORD Focus Bj. 2004-2007
- FORD C-Max Bj. 2003-2007
- FORD Galaxy Bj. 2006-2008
- FORD Kuga ab Bj. 2006-2008
- FORD S-Max Bj. 2006-2008
- FORD Transit Bj. 2006-2009
- FORD Transit Connect Bj. 2006-2009

### Only in conjunction with the following factory radios:

- Ford 5000C
- Ford 6000CD
- Sony CD 132
- Sony C 214
- Sony C 307
- Sony CDX SF 160 (nicht kompatibel mit Sony CDX FS 34X)

### Connect the adapter:

1. Remove the radio (you will find various instructions on the internet).
2. Before you disconnect the plug from the radio, make sure that the radio code is available to you, as you may need it for the radio after the power is interrupted.
3. Plug the Bluetooth Adapter WM-BT50 between the vehicle wiring harness and the factory radio.
4. In chamber B (red countersigned in the picture) sits the AUX input. This must be unlocked and is occupied by the Bluetooth adapter.



5. Now connect the red cable (ignition plus + 12V) to a switched + 12V line. Since this line behind the radio is no longer available, you can pick up the voltage from the cigarette lighter or air conditioning (measurement with multimeter necessary). Ignition on = + 12V are on / Ignition off = 0V are on.
6. Establish a Bluetooth connection by activating Bluetooth pairing and searching for the ``WM`` Bluetooth device. You should then set the volume to full volume on the connected device.
7. Before reinstalling the radio, test the function of the adapter. To do this, switch on the AUX function in the menu.

### **For info!**

The AUX function must be selectable or enabled!

Has something been left unclear? You can reach us MO-FR, from 8-17 o'clock under the  
E-Mail: [service@watermark-germany.de](mailto:service@watermark-germany.de)