

Quick Guide Bluetooth Music Receiver WM-BTMIC43

Compatible with the following models:

- **Audi RNS-E Navigation (Navigation Plus)**
- AUDI A3, A4 ,A6 (2004-2005), AUDI TT, AUDI R8, AUDI A8 (2001-2002)
- Lamborghini Gallardo

Connect the adapter:

1. Remove the radio (you will find various instructions on the Internet).
2. Before disconnecting the plugs from the radio, make sure that the radio code is available to you, as you will need it for the radio after the power interruption.
3. Plug the grey AMP extender of the WM-BTMIC43 into the provided connector behind the radio.



4. Now connect the black ground cable to the radio housing or the black cable directly to a ground cable to the radio connection (usually a thick brown cable). Without a good ground connection the function of the adapter is not given.
5. Now connect the red cable (ignition plus +12V) to a switched +12V line. Since this line is usually no longer present behind the radio, you can tap the voltage from the cigarette lighter, fuse box (terminal 15) or the air conditioner (measurement with multimeter necessary). Ignition on = +12V on / ignition off = 0V on.
6. Position the microphone near the driver in the vehicle (steering wheel fairing, dashboard, etc.). Lay the cable and connect the jack plug to the jack socket (MIC) on the WM-BTMIC43. Now connect the jack plug of the AUX adapter, which is already installed, to the SPK jack connector (see point 3). **Avoid placing the microphone in the immediate vicinity of or on airbags.**
7. Establish a Bluetooth connection by enabling Bluetooth pairing and searching for the Bluetooth device ``WM``. You should then set the volume on the connected device to full volume.
8. Before you reinstall the radio, test the function of the adapter. Turn on the AUX function on the radio.

32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	32	Pin	AMP	Connector	
16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1					
1	N. C.						8	N. C.			15	In-sync				22	AUX-NF-In-Left		29	NF-In-Left
2	N. C.						9	N. C.			16	In-G				23	N. C.		30	RGBS-In-GND
3	N. C.						10	N. C.			17	N. C.				24	N. C.		31	In-B
4	N. C.						11	N. C.			18	N. C.				25	N. C.		32	In-R
5	N. C.						12	N. C.			19	N. C.				26	N. C.			
6	AUX-NF-In-Right						13	NF-In-Right			20	N. C.				27	N. C.			
7	N. C.						14	SHIELD GND			21	AUX-NF-GND				28	NF-In-GND			

For Info!

The AUX input on the radio must be enabled. If AUX cannot be selected, it must be enabled in a specialist workshop.

Anything unclear? You reach us MO-FR, from 8-17 o'clock by e-mail: service@watermark-germany.de